



HOW TO FILL YOUR NEW CARTRIDGE

1



Take the rubber plug off the opening

2



Take the syringe given in the kit and insert it in the **opening** and **not the air vent!**

3



Plug the opening back up with the rubber plug

4



Attach the mouthpiece and make sure to take a couple dry hits without the battery attached to ensure the device is purged

